

1-component STP adhesive

PALLMANN P4

Solvent-free 1-component STP wood flooring adhesive

PRODUCT DESCRIPTION:

1-component STP multi-ply wood flooring adhesive with hard elastic adhesive ridge for the time-saving and economic installation of multi-ply wood flooring. Solvent-free and water-free, therefore very easy-to-use without any dimensional swelling of the wood flooring.

AREA OF APPLICATION:

1-component STP multi-ply wood flooring adhesive with hard elastic adhesive ridge for the time-saving and economic installation of multi-ply wood flooring. For interior use.

SUITABLE FOR:

- ▶ cementitious screeds, calcium sulphate screeds or concrete
- ▶ new, firmly screw-fixed chipboard P4 – P7 or OSB 2 – OSB 4 panels
- ▶ levelling compounds for multi-ply wood floors
- ▶ warm water underfloor heating systems



TECHNICAL DATA:

Packaging:	plastic container
Packsize:	16 kg
Shelf life:	months
Consumption:	approx. 1.000 - 1.200 g/m ²
Verarbeitungsklima	at least 15° C on the floor
Working time:	approx. 30 minutes*
Load-bearing:	after approx. 36 hours*
Final strength:	after approx. 5 - 7 days*

*At 20 °C and 50 % rel. humidity

PRODUCT BENEFITS / PROPERTIES:

- ▶ hard-elastic ridges
- ▶ very good ridge formation
- ▶ adhesive residues on wood flooring can be removed easily
- ▶ replacement adhesive according to TRGS 610
- ▶ Solvent-free, containing methoxysilane
- ▶ EMICODE EC 1 PLUS / Very low emission



NOTE:

All mineral substrates as well as good gritted mastic asphalt to conform to standards has to be primed with UZIN PE404.

SURFACE PREPARATION:

The substrate must be even, level, sound, dry, free from cracks and free from materials which could impair the adhesion. Check the substrate according to the applicable standards and report any deficiency. Cement and calcium screeds must be abraded and vacuumed off.

For wood flooring work particularly careful testing of the subfloor is recommended. Thoroughly brush, abrade, grind or shot-blast, to remove any weak or soft surface areas or layers reducing the adhesion e.g. old adhesive residues. Thoroughly vacuum off the surface.

Prime calcium sulphate screeds, accelerated cement screeds, rapid cement screeds, underfloor heating systems and special screed constructions with UZIN PE404. The product data sheets of the products used must be observed. Prime uneven or very rough substrates with UZIN PE 360 PLUS universal primer and apply UZIN NC151 smoothing compound to a minimum thickness of 3 mm. All mineral substrates, as well as good gritted mastic asphalt, which conforming to standards, has to be primed with UZIN PE404.

Refer to the product data sheets for the products used.

APPLICATION:

1. Before use, the container must be brought to room temperature (20 °C). After opening, remove the cover film and if necessary, remove any skin that may have formed on top of the adhesive. Do not mix it in.
2. Apply evenly onto the substrate using a suitable notched trowel. Only apply as much adhesive as can be covered with wood flooring in approx. 20 minutes.
3. Lay the woodfloor pieces into the adhesive bed and press well down. Ensure full adhesive transfer to the underside of the wood floor.
4. Using wedges, leave a gap of approx. 10 mm between the wood flooring and the wall.
5. Remove adhesive residues with cleaning cloths of the UZIN CLEAN-BOX while fresh. Adhesive residues can be rubbed off with extra effort when cured.

IMPORTANT NOTES:

- ▶ Optimum temperature is 18 to 25 °C, floor temperature at least 15 °C, relative humidity between 35 % and 65 %. Low temperatures extend, high temperatures shorten the pot life, laying- and setting time.
- ▶ Shelf life minimum 12 months in original packaging when stored in dry conditions. Protect from freezing and do not expose to temperatures over 40 °C.
- ▶ Tightly reseal opened containers and use the contents as quickly as possible.
- ▶ By installing the large-size elements, a raised evenness of the subsoil should be achieved. The use of PALLMANN solid board notch trowel is recommended.

- ▶ Warning! There is a risk of dimensional swelling if wood flooring has dried below standard levels at an increase of the air humidity.
- ▶ To be used for exotic wood types only after a written installation recommendation by the manufacturer.
- ▶ When installing UZIN Multimoll Fleece/UZIN Multimoll Fleece Plus with adhesive, care must be taken to ensure that the premises are well ventilated, e.g. through open windows or doors. In rooms with no airflow, the movement of air must be ensured by using mechanical aids, e.g. blowers / fans.
- ▶ The following standards and notices are applicable and especially recommended: DIN 18356 (Working with wood flooring), TKB notice 1 (Bonding wood flooring), TKB notice 8 (Assessing and preparing substrates for covering floors and work with wood flooring), BEB notice (Assessing and preparing substrates).

PROTECTION OF THE WORKPLACE AND THE ENVIRONMENT:

Solvent-free adhesive containing methoxysilane. Non flammable. Avoid contact with eyes and skin. When curing, produces traces of methanol. Ensure good ventilation during application. Wear protective gloves. After contact with skin wash with plenty of water and soap. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. Observe safety information on product label as well as safety data sheet.

DISPOSAL:

Where possible, collect product residues and re-use. Do not allow dispersal into drains, sewers or ground. Empty, scraped and drip-free containers are recyclable. Containers with liquid residue, as well as the liquid product, are classed as Special Waste. Dried product residues are classed as Construction Waste. Therefore collect waste material and allow to harden, then dispose as Construction Waste.